



Roller holder shelf. Remove shelf for added storage below.



Place trash can liner over bag holder sides. Do not let trash can liner drape over outside display panels.



Feed Sani-Wipe or center pull paper towel through anti-ropeing slide bar tensioner. Adjust tension by sliding the bar left or right.

